

PROFLEX REBOND-IT™

FLOORING REPAIR AND BONDING COMPOUND

DESCRIPTION:

Proflex REBOND-IT™ is an easy to use bonding compound designed to rebond loose or hollow tiles without the costly expense of replacing them. The compound is a safe, easy to install, and easy to clean, is used by tile professionals and builders to provide an economical alternative to removing and resetting tiles.

ADVANTAGES:

- Easy to use
- Cures in as little as 10 hours
- Bonds to most surfaces
- Quick Cleanup
- Eliminate the expense of tear out and reinstallation of tile

SUTIABLE SURFACES

- CERAMIC TILE
- QUARRY TILE
- PORCELAIN TILE
- STONE
- MARBLE
- GRANITE
- TERRAZZO

PACKAGING: Proflex REBOND-IT™ offers a variety of sizes to match the needs of your project.

- 10oz TUBES (24 tubes / 1CT)
- 32oz TUBES (12 tubes / 1CT)
- 1Gal. Container (4 gal. / 1CT)
- 5 Gal. Container (36 Ct / 1PA)

INSTALLATION INSTRUCTIONS:

STEP 1: IDENTIFY LOOSE AND OR HOLLOW TILES

Identify the tile(s) that will need to be re-bonded. (Tap the surface of a tile, hollow sounding tiles will be in need of repair)

STEP 2: PREPARING THE AREA TO BE FILLED

Using a masonry bit, bore holes in 6 places in the grout surrounding each loose or hollow tile needing repair, (Be sure to use a bit slightly smaller than the grout joint). Additional penetrations may be required. Clear loose debris from the holes thoroughly. This can be accomplished by forcing air from the holes by tapping the surface with a rubber mallet.

STEP 3: APPLICATION OF REBOND-IT COMPOUND

Fill Rebond-It™ into each hole. There may be some initial resistance to filling the penetrations, apply additional, but not excessive, force to continue the fill. While filling the penetrations, tap the surface area with a rubber mallet to monitor the fill of the Rebond-It™. Wipe away excess Rebond-It™ with a wet sponge, and follow with a dry sponge. Place a weight (25-30lbs) on each repaired surface for a minimum of 10 hours to allow Rebond-It™ to activate. Additional time may be necessary. After Rebond-It™ has sufficiently bonded, penetrations may be filled with grout matching original color. Remove any excess Rebond-It™ from penetrations with a knife or razor blade by using a vacuum on the penetrations.

PRODUCT LIMITATIONS

Do not freeze product, Use only in temperatures above 42°F. Additional applications may be necessary to achieve desired results. Even then, complete coverage may not be achieved. Do not use in showers, pools, or areas where moisture is present. Discoloration of grout adjacent to entry holes is possible. PROFLEX recommends testing application in a non-conspicuous area prior and wait 24 hours prior to full application. The suitability of use for this product is the sole responsibility of the user.

CAUTION:

Eye and skin irritant, Promptly wash eyes with water for 15 minuets. Consult physician if irritation persists. Skin contact should be washed with soap and water. If inhaled, get to fresh air immediately. If ingested, drink several glasses of water immediately, and call a physician or poison control center.

PROFLEX PRODUCTS, INC.

Phone: 877-5PROFLEX
(877-577-6353)

Fax: 239-403-0714

Web: www.proflex.us

